Subject: Re: Pushed in Dust Cap Posted by Wayne Parham on Mon, 24 Jul 2006 05:24:16 GMT View Forum Message <> Reply to Message

There's a "good" way and a "better" way to fix a dented dust cap. You can use a needle like a hook, pressing it into the cap and using it to pry out the dent. That's a good way to do it. A better way is to buy a replacement cap, cut the old one off and glue on a new one.

Page 1 of 1 ---- Generated from AudioRoundTable.com