

---

Subject: Pioneer RT - 909

Posted by [Minas](#) on Fri, 19 Dec 2008 20:28:03 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hello, I have Pioneer RT 909, problem is, sometimes it plays and record very nice and easy, and sometimes seems it LOCKS and no move at all!! Its in LOCK MODE!!! I can't play either way! And No recording either. Like I said it LOCKS, and no move at all! If somebody can help me what I've suppose to do?! Rewind or Fastforward runs great.Thanks, Minas

---