Subject: Re: Blow Fuse!
Posted by Wayne Parham on Mon, 22 Jan 2007 18:34:18 GMT
View Forum Message <> Reply to Message

The current level that causes the lamps to glow brightly is 2 amps.  They begin to compress the signal around half that level and fuse somewhere around twice that level.