

---

Subject: Re: Blow Fuse!

Posted by [Wayne Parham](#) on Mon, 22 Jan 2007 18:34:18 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The current level that causes the lamps to glow brightly is 2 amps. They begin to compress the signal around half that level and fuse somewhere around twice that level.

---