
Subject: Re: Mid-horn questions

Posted by [Peter K](#) on Wed, 16 May 2007 06:38:32 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi Wayne, Thanks a lot again! One final question: I understand that the 7Pi version uses no back chamber whereas the 9Pi version uses 80 inch³ back chamber. In plain words: what does it do to the sound when you remove the back chamber? Thanks! Regards Peter
