Posted by Beltway Bandit on Wed, 13 Jun 2007 13:45:41 GMT
View Forum Message <> Reply to Message

One last question for now - the Alpha 10 .pid file that ships with the pi align software doesn't match the data from the Alpha 10 .pdf from the mfg.  Should I use the .pid that ships or modify it according to the cut sheet?