

---

Subject: Re: Tape dragging

Posted by [Wayne Parham](#) on Tue, 29 Jun 2004 22:15:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I've got some tapes that do that too, and I've always found it to be caused by the tape. Cassette tapes can sometimes be repaired by opening up the cassette, removing the tape spools, and installing in another cassette case. It's really handy to use a cassette case that is fastened with screws, as you don't have to worry about breaking it or getting glue on the spools.

---