

---

Subject: Re: Buzzing mic

Posted by [Adveser](#) on Tue, 19 Oct 2010 23:31:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

There is a short in the ground wire. If you using a 1/4 adapter make sure that the ground and the negative poles are soldered together or use an XLR to XLR cable.

Get a mic stand that is not using metal to hold the mic. All the ones I've used use plastic harnesses. Or wrap the mic housing is electrical tape.

---