Subject: AMP cracking and popping
Posted by compguy on Thu, 25 Nov 2010 01:47:01 GMT
View Forum Message <> Reply to Message

When ever I plug my guitar into the input on my amp and start playing, even if the amp is not up very high, I get a pop every so often. It doesn't seem to happen all the time, and usually not when I'm playing anything in particular. I checked my input, and it does seem slighly loose. Does this sound like a serious problem?