

---

Subject: Re: Driver Removal

Posted by [Wayne Parham](#) on Tue, 25 Oct 2011 14:44:53 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I use an Allen wrench to lift the woofer (or horn) from the mounting holes. Remove all the screws, and put a decent size Allen wrench in the hole. Tilt until it catches and lift out, basically using the wrench as a prybar.

---