

---

Subject: Re: yamaha turntable yp-b2 on switch?

Posted by [Wayne Parham](#) on Mon, 19 Dec 2011 20:05:34 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I don't have one of those turntables either, but I do know several that start when the tone arm is lifted and moved towards the platter. Could it be that's the way yours works too? Have you tried lifting the tone arm and moving it towards the platter?

---