Subject: Re: Alpha 10 modeling Posted by rvsixer on Tue, 20 Dec 2011 15:48:24 GMT View Forum Message <> Reply to Message

Sorry for bringing back an old thread (and hope the OP does not mind). This just seemed a relevant place for my question without starting a new one.

I'm a winisd/modeling newbie, for the 2pi towers I am seeing xmax at only 2.2W input, while its posted here we can send 100W through the passband . What am I doing wrong?

Inputs: Alignment: tried all of them (what is the correct one, EBS?) Volume: 129 liters Port dia: 11.43 cm Port length: 1.59 cm

