Subject: Any ideas for fixing this? Posted by TurnItUp on Mon, 06 Aug 2012 18:07:04 GMT

View Forum Message <> Reply to Message

We have one of those portable dvd players and my little girl has been pulling on the cord I guess. Now when you touch the cord it makes the audio crackle. Is there anything I can do to fix this or is just shot?