

---

Subject: Intermittent Drop Outs

Posted by [Nymeria](#) on Mon, 25 Aug 2014 13:50:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Intermittent sound drops are usually the result of a loose electrical connection, right? I don't hear any buzzing or humming and the drops seem totally random. Loud noises or vibration don't seem to correlate to the dropouts, which makes me wonder. I would think a loose connection would always drop in that case.

---