

---

Subject: Re: Intermittent Drop Outs

Posted by [Nymeria](#) on Tue, 26 Aug 2014 13:50:48 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'm sorry for not being clearer. It's an mp3 player (which plays fine all the time) plugged into a mixer and out to stereo speakers. The right speaker drops out.

---