
Subject: Rs in Four Pi Crossover

Posted by [timhowell01](#) on Sat, 17 Jan 2015 20:08:36 GMT

[View Forum Message](#) <> [Reply to Message](#)

I was assembling my Four Pi crossovers this morning and almost missed Rs. This is a *really* simple question, but just want to make sure that I'm correctly reading that Rs is a 16 ohm resistor across the terminals of the compression driver. Is that right? I'm wiring my crossovers point to point. Can I just solder the resistor to the driver?
