
Subject: Headphones With No Sound

Posted by [Airforce 3](#) on Fri, 05 Feb 2016 15:00:25 GMT

[View Forum Message](#) <> [Reply to Message](#)

Why am I getting no sound on my headphones? They're plugged in to a front jack and I can see the sound metre moving, but no sound. Any ideas? I've tried everything.....I think.
