
Subject: Humming sound while recording cds
Posted by [Finn](#) on Wed, 02 Mar 2016 17:43:36 GMT
[View Forum Message](#) <> [Reply to Message](#)

I just recently purchased a Tascam cd recorder that I hooked up to my amp. I keep getting a humming sound through the speakers that goes away when I unhook the rca cables. Will this sound have any affect on the recording process and if so, how can I get rid of it?
