

---

Subject: Re: ASL Si15-DT

Posted by [Manualblock](#) on Tue, 27 Jul 2004 22:49:58 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thanks for the reply I wasn't sure if you mean't plate current. I think I am reading the tube load lines wrong. For the 6L34 I have a zero signal plate current of 100 ma, and plate voltage of 250 running in class a1. Is that right or am I in la-la land with this?

---