

---

Subject: Re: No sound on laptop

Posted by [gofar99](#) on Tue, 31 Jan 2017 23:10:35 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi, Depending on the laptop it is probably a setting. On mine (a Toshiba) if you click on the speaker icon at the bottom of the screen it will bring up a menu that shows what device (speaker, phones etc) is being used. Just select the one you want. Alternatively you may have muted the speaker, just click the icon to undo it. Other possibilities are found in the settings section of the control panel. There are too many variations from brand to brand to give you definitive guidance there. If you tell us what model it is maybe we can help more.

---