Subject: Re: Troubleshooting Posted by Gemmel on Thu, 09 Feb 2017 01:02:30 GMT View Forum Message <> Reply to Message

I wish I could offer better answers but the best I can think of right now is to disconnect it, take out all the cables and re-connect everything all over again.

Page 1 of 1 ---- Generated from AudioRoundTable.com