

---

Subject: Re: Troubleshooting

Posted by [Hylo](#) on Thu, 09 Feb 2017 14:49:06 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

If the whole thing's not turning on, check your power. If that doesn't help, then disconnect each component in turn, and see if you can isolate the problem area. If you have some spare good cables, then swap those cables in and if the problem goes away, swap the old ones back one at a time until you've isolated the bad cable. I'm kind of assuming you don't have a cable tester available.

---