
Subject: Re: rogue 88 amp
Posted by [jim](#) on Sun, 07 Nov 2004 13:39:55 GMT
[View Forum Message](#) <> [Reply to Message](#)

i have a blown output fuse in my rogue 88 (to transformer), I am unable to read the rating, the manual does not help. Any clue ?thanks
