

---

Subject: USB Drive Won't Play

Posted by [Leot55](#) on Sat, 29 Jul 2017 20:52:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

My father is here and he'd like to see our Disney photos. Unfortunately, I can't get the USB to work. I have my manual and have worked through the troubleshooting steps first before asking here. The t.v. is on. The USB stick is compatible with the television set. I have the USB stick in the correct slot. My cords are plugged in correctly, but nothing is happening on the screen. Any suggestions?

Did I put this thread in the correct spot? I wasn't sure whether it should go here or in the general area.

---