
Subject: oops....

Posted by [PakProtector](#) on Mon, 31 Jan 2005 00:40:24 GMT

[View Forum Message](#) <> [Reply to Message](#)

hey-Hey!!!,my bad, I forgot to answer the question. I got distracted in my ranting...Ra is the SE load in the example given. You'd double its value to expand the model to PP.regards,Douglas
