Subject: Bass Knob Problem Posted by Groot on Tue, 25 Jun 2019 14:05:31 GMT

View Forum Message <> Reply to Message

My computer speaker has a problem with the bass knob. The bass is hard to balance because there were times when the bass will be totally gone when I adjust the knob. It is like picking a locked door, turning the picks slowly to get the right position in order to open the door, the bass in the case of my speaker.