
Subject: Re: Cassette Tape Alignment

Posted by [Wayne Parham](#) on Fri, 12 Jul 2019 20:50:12 GMT

[View Forum Message](#) <> [Reply to Message](#)

Next is a speed adjustment. Using the 3kHz signal, adjust the speed potentiometer to be exactly 3kHz.

You can see mine was off a little bit. A small turn of the speed adjustment potentiometer RV71 brings it right to where it needs to be.

File Attachments

- 1) [Speed_Before.png](#), downloaded 617 times
 - 2) [Speed_Set.png](#), downloaded 647 times
-