

---

Subject: 3Pi Acoustic Axis and Listening Distance  
Posted by [Symphonimind](#) on Sat, 14 Dec 2019 04:05:48 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Dear Mr. Wayne,

I have a small room which is around 3m Width x 3.4m Length. I want to ask 2 questions:

1. Where is the acoustic axis of 3Pi? Is that in the middle of two drivers?

I am really familiar with Genelec monitor, they always draw clearly where acoustic axis is so I can easily aim their monitors.

For example:

[https://assets.ctfassets.net/4zjzn055a4v/2jXvV7G8iwQOekEss8ycKU/14f746cc5074382a1826481b6da45b35/8330a\\_views\\_0.pdf](https://assets.ctfassets.net/4zjzn055a4v/2jXvV7G8iwQOekEss8ycKU/14f746cc5074382a1826481b6da45b35/8330a_views_0.pdf)

2. Which is the minimum acceptable listening distance from 3Pi to listeners in my situation (small room)? In my situation, I will not sit at the far behind the frontwall like normal audiophile, I sit close to the monitors, and close to the frontwall.

The room is professionally treated to be neutral down to at least 30Hz.

Thank you very much.

---