
Subject: Re: Trigger finger is itchy
Posted by [Rusty](#) on Sat, 10 Oct 2020 17:12:43 GMT
[View Forum Message](#) <> [Reply to Message](#)

Thanks both of you and Wayne specifically. Where would the shield portion go? Some ground point on the case? Still though, the design doesn't use shielded inputs or outputs, or sleeve ground. Just the single wire to the center tip. I'm not sophisticated enough to know his justification. Any ideas? If this is a chronic dilemma I'm facing. Reckon I'd give anything a try. The noise is constant, on all switched inputs, doesn't go up in loudness with volume control, or gain control. Thanks for any tips.
