Subject: Speakers are humming
Posted by Madison on Fri, 11 Dec 2020 03:32:19 GMT
View Forum Message <> Reply to Message

Two of my speakers have started humming when they're plugged in and turned on. The hum doesn't change with the volume, so I guess it's probably a ground loop issue that's causing the hum. But why is it happening when nothing has changed in the room? Nothing has been moved, no cords have been switched, nothing has happened. The humming just started. I'm not sure how to fix it in this instance.