Subject: low channel output problem Posted by jim denton on Mon, 10 May 2004 13:35:36 GMT View Forum Message <> Reply to Message

I have a tube amp MC-30) that is not putting out the same power to both channels ---the left channel is fine and the right channel is aomost gone---what's the fix??? re-cap the output caps first? JD

Subject: Re: low channel output problem Posted by Bill Wassilak on Mon, 10 May 2004 14:47:16 GMT View Forum Message <> Reply to Message

First thing I would try is to swap the tubes between the 2 channels see if it still acts that way. If does then I'd check the voltages at the tube bases. But be careful EXTREMELY HIGH VOLTAGES there. If it follows the tubes when you switch them around you could have just a bad tube.HTHBill W.

Subject: Re: low channel output problem Posted by Thermionic on Tue, 11 May 2004 21:20:28 GMT View Forum Message <> Reply to Message

Jim Denton, I'm somewhat confused here. Maybe I'm just not understanding what your amp is. By MC-30, do you mean the McIntosh monoblocks? Thermionic

Page 1 of 1 ---- Generated from AudioRoundTable.com