

---

Subject: Atwater Kent Shortwave model 37  
Posted by [jgavril](#) on Tue, 31 Aug 2010 22:12:57 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Does anyone have a diagram of how the variable capacitors are supposed to be timed to one another and what material is used for the belts? I can't see how it would be string??

---

---

Subject: Re: Atwater Kent Shortwave model 37  
Posted by [capbuster](#) on Thu, 02 Sep 2010 22:50:39 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Might find it here <http://www.theoldradiofixerupperguy.com/dial%20cord.html>  
Has lot's of dial string guides.

---

---

Subject: Re: Atwater Kent Shortwave model 37  
Posted by [capbuster](#) on Thu, 02 Sep 2010 22:59:46 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

jgavril wrote on Tue, 31 August 2010 17:12 Does anyone have a diagram of how the variable capacitors are supposed to be timed to one another and what material is used for the belts? <http://www.nostalgiaair.org/Resources/3441m0001344.html> or at [http://www.nostalgiaair.org Resources](http://www.nostalgiaair.org/Resources).

---