

---

Subject: Sub in auto mode

Posted by [Wonderwoll](#) on Mon, 18 Oct 2010 09:52:56 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

When I bought my sub the sales guy advised me to leave it in auto mode all the time. he didn't give me any reason for this and I would prefer to switch it off when it's not in use. Can I damage it in some way by doing this?

---

---

Subject: Re: Sub in auto mode

Posted by [jazzlover](#) on Mon, 18 Oct 2010 12:12:05 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The auto mode lets the sub go idle and stop drawing current when not in use. You can certainly do it manually if you wish. No damage to be expected.

---