Subject: Can't get music to burn!
Posted by Hoptoit on Mon, 31 Jan 2011 00:33:21 GMT
View Forum Message <> Reply to Message

I am trying to burn some cds for my daughter and they won't burn. I mean it shows they are burning (from iTunes) but when we play the cds there is nothing there. What could be the problem?