

---

Subject: Any ideas for fixing this?

Posted by [TurnItUp](#) on Mon, 06 Aug 2012 18:07:04 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

We have one of those portable dvd players and my little girl has been pulling on the cord I guess. Now when you touch the cord it makes the audio crackle. Is there anything I can do to fix this or is just shot?

---

---

Subject: Re: Any ideas for fixing this?

Posted by [Wayne Parham](#) on Mon, 06 Aug 2012 19:22:05 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The cable is broken internally. The reason it crackles is when you move it, the connection makes and breaks. I would suggest simply replacing the cable.

---

---

Subject: Re: Any ideas for fixing this?

Posted by [Chicken](#) on Tue, 07 Aug 2012 18:27:30 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I agree with Wayne; the cable is broken.

Fortunately cables are relatively cheap. I hope your daughter learns to stop pulling on the cord so you won't have to replace it again.

---