

---

Subject: Add jingle to in-store music

Posted by [mlevans](#) on Tue, 10 Nov 2015 03:19:51 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Trying to figure out how to configure my audio system to play company jingle every 3 minutes or so then return to music. I use standard Bogen 70V system with several inputs and mute capability.

Every 360 seconds or so I want to mute the music and play the jingle.

Jingle is in continuous loop but how do I mute the audio just at the start the jingle? How do I coordinate things so the jingle plays from the beginning each time?

Thanks for your help.

---

---

Subject: Re: Add jingle to in-store music

Posted by [Wayne Parham](#) on Tue, 10 Nov 2015 16:41:48 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Bogen has several systems available, and the instructions for doing what you need to do are specific to the system. So contact Bogen for support. They should be able to help you.

---

---

Subject: Re: Add jingle to in-store music

Posted by [Kingfish](#) on Tue, 01 Dec 2015 12:58:32 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Can't you just put the jingle on a timer? Leaving 3 seconds or so between the end of music and the start of the jingle? This is standard technology that I'm sure Bogen can accommodate.

---