
Subject: Headphones With No Sound
Posted by [Airforce 3](#) on Fri, 05 Feb 2016 15:00:25 GMT
[View Forum Message](#) <> [Reply to Message](#)

Why am I getting no sound on my headphones? They're plugged in to a front jack and I can see the sound metre moving, but no sound. Any ideas? I've tried everything.....I think.

Subject: Re: Headphones With No Sound
Posted by [Wayne Parham](#) on Fri, 05 Feb 2016 20:36:22 GMT
[View Forum Message](#) <> [Reply to Message](#)

Are you sure the headphones work?

Have you used them in something else recently?

Subject: Re: Headphones With No Sound
Posted by [gofar99](#) on Sat, 06 Feb 2016 17:37:48 GMT
[View Forum Message](#) <> [Reply to Message](#)

Hi, Are you sure there is a headphone level signal at the jack? It might be an input jack for a mic. There might also depending on what you are using a setting or switch to enable the headphone jack.

Subject: Re: Headphones With No Sound
Posted by [Airforce 3](#) on Mon, 15 Feb 2016 17:53:31 GMT
[View Forum Message](#) <> [Reply to Message](#)

A friend gave them to me because he upgraded. They worked just fine on his system. I'm still fiddling with it, so I'll look into the compatibility angle.
