Subject: SONY PS LX250H voltage Posted by abcdefgh on Fri, 20 May 2005 11:59:30 GMT View Forum Message <> Reply to Message

how do i change the voltage of the sony PS LX250H to 220.....

Subject: Re: SONY PS LX250H voltage Posted by Manualblock on Fri, 20 May 2005 23:48:44 GMT View Forum Message <> Reply to Message

Who wants to know?

Subject: Re: SONY PS LX250H voltage Posted by Wayne Parham on Sat, 21 May 2005 13:09:04 GMT View Forum Message <> Reply to Message

You can use a transformer but it costs more than your turntable does. You're probably better off getting another turntable.

Subject: Re: SONY PS LX250H voltage Posted by Manualblock on Sat, 21 May 2005 14:32:06 GMT View Forum Message <> Reply to Message

Why indulge this guy whoever he is. I wish I had the free time to waste everyone elses.

Subject: Audiophile turntables or budget models Posted by Wayne Parham on Tue, 24 May 2005 13:26:55 GMT View Forum Message <> Reply to Message

I still think it's someone with a high-end turntable site that wants to load us up with hundred dollar turntable posts, in order to draw more of that type of traffic here via search engines. They must be concerned we'll divert attention away from them or something. But in case the posts are legitimate, sometimes I offer a reply or suggestion. And sometimes I don't.

A guy with abcdefg as a moniker?? Well; two can play at that game.

Subject: Re: Audiophile turntables or budget models Posted by Wayne Parham on Tue, 24 May 2005 13:54:19 GMT View Forum Message <> Reply to Message

I thought the same thing.

Page 2 of 2 ---- Generated from AudioRoundTable.com