
Subject: Um.. I am the Village Idot but it won't turn on...
Posted by [Amanda](#) on Sat, 10 Sep 2005 07:11:49 GMT
[View Forum Message](#) <> [Reply to Message](#)

OK i feel dumb. I've recently 'inherited' an '70 Bsr Professional 2260 AG from my folks. I can't get the thing to turn on. It seems like the slide selector, the thing that you move to turn the player to 'off', 'on', or 'auto' is stuck. It simply will not move. It is plugged in to a power source. That was the first thing my Dad asked when i sought his advice. His response to my dilemma is that he hasn't looked at the thing in 20 years so i'm on my own. Is there a trick to this thing? Any suggestions?

Subject: Re: Um.. I am the Village Idot but it won't turn on...
Posted by [Wayne Parham](#) on Sun, 11 Sep 2005 10:47:55 GMT
[View Forum Message](#) <> [Reply to Message](#)

Sounds like you gotta find a way to un-jam that switch. Take it to a repair shop and see what they say. Find one locally that gives free estimates.

Subject: Re: Um.. I am the Village Idot but it won't turn on...
Posted by [Amanda](#) on Sun, 11 Sep 2005 17:09:31 GMT
[View Forum Message](#) <> [Reply to Message](#)

ok. Thanks. I feel better now there actually is something wrong with it.
