Subject: denon dp-47f
Posted by jaudio on Sat, 15 Oct 2005 18:57:27 GMT
View Forum Message <> Reply to Message

The problem I have is the platter wont turn. I can feel the motor vibrating but not turning. I measured the voltage on motor pcb,I'm getting -13.75 and +9.45(the stated voltage is +/-12) Any help?Thanks