

---

Subject: Yamaha YP-B4 sound coming is very low  
Posted by [Virgil](#) on Wed, 21 Jun 2006 15:59:42 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Hi,I just acquired a Yamaha YP-B4, replaced it with a new belt and a new AT stylus. 1- There is very little sound or no sound at all coming out. I had an ADS turntable and works fine with all my audio equipments. Does this have something to do with Magnetic or Moving coil cartridges? 2- The tonearm does not lie properly nor slide at all thru the vinyl when I press "start".Any input will be appreciated.

---

---

Subject: Re: Yamaha YP-B4 sound coming is very low  
Posted by [Wayne Parham](#) on Wed, 21 Jun 2006 17:33:11 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

You probably need a phono stage for the turntable, and moving coil cartridges are different than moving magnet types, so you need a phono stage appropriate for your cartridge. Most have settings and can work with either.

---