

---

Subject: Sony Turntable Loud Hum  
Posted by [Shane M.](#) on Wed, 04 Oct 2006 22:55:44 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

I recently purchased a Sony PS T15 turntable off ebay and when i hooked it up it has a very loud hum. It sounds like a dead short, not a 60 cycle buzz. There is no ground wire so i tried connecting one from the chassis to my stereo but it didn't help. Any thoughts?

---

---

Subject: Re: Sony Turntable Loud Hum  
Posted by [Wayne Parham](#) on Sun, 08 Oct 2006 16:23:57 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Are both channels of the cartridge connected? In other words, can you hear sound from both channels through the hum? If not, that may be the culprit. An open line can be pretty noisy, with long wires having no termination.

---

---

Subject: Re: Sony Turntable Loud Hum  
Posted by [Shane M.](#) on Sun, 08 Oct 2006 22:06:50 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Thanks for the reply. Hum is from both channels however, the hum stops when i remove the holder/cartridge from the end of the arm. So i swapped out the cartridge with an older one and the hum is back, so i ruled out a bad cart unless both are bad. I am going to try to replace both RCA cables to see if that's it. There is no ground wire, is this normal? Thanks again.

---

---

Subject: Re: Sony Turntable Loud Hum  
Posted by [Wayne Parham](#) on Mon, 09 Oct 2006 13:58:01 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

If you don't have a ground wire, that's probably it. Connect the chassis and arm to the ground lug on your preamp.

---

---

Subject: Re: Sony Turntable Loud Hum  
Posted by [Shane M.](#) on Mon, 09 Oct 2006 22:27:36 GMT

---

Problem completely solved. Thank you!

---