

---

Subject: Dumb Turntable Question

Posted by [TurnNovice](#) on Sun, 22 Oct 2006 14:21:37 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Greetings-I just bought a Philips 270 turntable. The former owner demonstrated that it worked for me, so I don't think it is broken. However, being an idiot, I do not remember how he turned it on/got it to work. And after an hour or more of searching I cannot seem to find any switch etc. Apologies for the stupidity, but do any of y'all have any fixit ideas?-ben

---

Subject: Re: Dumb Turntable Question

Posted by [Wayne Parham](#) on Sun, 22 Oct 2006 16:09:44 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Maybe the motor starts when you lift the arm and move it towards the platter. Did you try that?

---