

---

Subject: Loosing quality

Posted by [Aorsearcher](#) on Mon, 23 Oct 2006 22:23:45 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Anyone knows why my vinyl records sound great on the first track and gradually loses quality on other tracks to finally on the last the sounds sounds horrible with a distorted midband!!!Please somebody help me.

---

Subject: Re: Loosing quality

Posted by [Wayne Parham](#) on Tue, 24 Oct 2006 21:16:54 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

You should probably adjust the arm setup. Sounds like stylus alignment is off in some way as the stylus nears the center of the platter. Check everything out, using the information in the link below:Turntable tone arm and cartridge setup

---