

---

Subject: Autoreturns too soon

Posted by [DKeller](#) on Thu, 22 Feb 2007 01:44:26 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

This is my first time posting, but I was wondering if anyone could help me figure out how to adjust the autoreturn position on my Fisher MT-6420 turntable. It's a direct-drive (if that makes any difference). It plays fine, but the autoreturn engages before the end of the record. Any ideas? Thanks.

---

Subject: Re: Autoreturns too soon

Posted by [Wayne Parham](#) on Fri, 23 Feb 2007 16:28:51 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

There's an arm position sensor that triggers the auto-return function. You might check with StereoManuals.com and see if they have a service manual that will tell you how to adjust it.