
Subject: Garrard 42 Turntable

Posted by [Adam](#) on Sat, 04 Apr 2009 18:38:49 GMT

[View Forum Message](#) <> [Reply to Message](#)

Why does my turntable hum? can this turntable be hooked up to any receiver with Phono input?
The turntable has a ground wire

Subject: Re: Garrard 42 Turntable

Posted by [Wayne Parham](#) on Tue, 07 Apr 2009 16:22:39 GMT

[View Forum Message](#) <> [Reply to Message](#)

Make sure the ground is connected and all the connectors are clean and tight. Sometimes an oxidized connector will cause that. Otherwise, if it isn't a connection or a wire, then it's the cartridge.
