
Subject: troubleshooting a tascam model 38 reel to reel
Posted by [Rob Payne](#) on Mon, 25 Jul 2005 22:00:31 GMT
[View Forum Message](#) <> [Reply to Message](#)

I have two identical tascam 38 1/2" 8 tracks reel to reel machines. Both of them i just recently purchased and both have the same problem. No i have not much experience with reel to reel but i'm good at figuring things out. So pardon my lack of knowledge of terms. ok so both machines started making a funny noise comming from the small spinning wheel to the right of the heads. (the one that always spins). Then they quit spinning and now the blow the 3amp fuses everytime i hit play or edit. nybody with any clue of whats wrong?

Subject: Re: troubleshooting a tascam model 38 reel to reel
Posted by [Wayne Parham](#) on Tue, 26 Jul 2005 01:31:28 GMT
[View Forum Message](#) <> [Reply to Message](#)

Sounds like the motor that drives the pinch roller is bad.

Subject: Re: troubleshooting a tascam model 38 reel to reel
Posted by [Cyclotronguy](#) on Tue, 26 Jul 2005 16:38:56 GMT
[View Forum Message](#) <> [Reply to Message](#)

Or the capstain bearing is dry, galled, fretted and etc.

Subject: Re: troubleshooting a tascam model 38 reel to reel
Posted by [Wayne Parham](#) on Tue, 26 Jul 2005 19:02:55 GMT
[View Forum Message](#) <> [Reply to Message](#)

Yep, could be.
