
Subject: Problem with Tascam 133
Posted by [Francois](#) on Fri, 16 Jun 2006 02:19:57 GMT
[View Forum Message](#) <> [Reply to Message](#)

Hello,I recently bought a Tascam 133 for 20\$ and found out that one channel is not playing. I get only mono sound. Even the VU meter is not moving. Any idea about what could be the problem?Thanks!

Subject: Re: Problem with Tascam 133
Posted by [Wayne Parham](#) on Fri, 16 Jun 2006 17:57:39 GMT
[View Forum Message](#) <> [Reply to Message](#)

Sounds like a tape head or connection to it. Examine the wires connected to the head.

Subject: Re: Problem with Tascam 133
Posted by [Francois](#) on Fri, 16 Jun 2006 19:11:53 GMT
[View Forum Message](#) <> [Reply to Message](#)

I forgot to mention that the headphone output is working fine (in stereo) so this must be something else.

Subject: Re: Problem with Tascam 133
Posted by [Wayne Parham](#) on Sat, 17 Jun 2006 15:25:25 GMT
[View Forum Message](#) <> [Reply to Message](#)

I see. That's a good clue, a symptom that will greatly help you narrow down the problem. Maybe the input level control potentiometer has opened. Time to get out the scope!

Subject: Re: Problem with Tascam 133
Posted by [bernard céline](#) on Mon, 05 Feb 2007 13:29:42 GMT
[View Forum Message](#) <> [Reply to Message](#)

hello,i would like to buy a Tascam133 but there is no manual with it.could you send me where i

can find one or send me the manual in my email.thanks a lot.have a nice day.céline
