
Subject: No power from my Wharfdale Active Pro 8.2 speaker
Posted by [Gabriel](#) on Sat, 17 Mar 2007 14:13:47 GMT

[View Forum Message](#) <> [Reply to Message](#)

The speakers worked fine this morning. Got home from work, fired up the computer and my right speaker has no power at all. Left speaker turns on no prob, blue on light etc. I've tried changing the power cable, outlets, everything. Is this thing fried? I have them plugged into my toneport UX2 and also using Guitar Rig 2.

Subject: Re: No power from my Wharfdale Active Pro 8.2 speaker
Posted by [Wayne Parham](#) on Mon, 19 Mar 2007 15:11:18 GMT

[View Forum Message](#) <> [Reply to Message](#)

Sounds like the power supply may have popped.

Subject: Re: No power from my Wharfdale Active Pro 8.2 speaker
Posted by [Gabriel](#) on Wed, 21 Mar 2007 10:23:54 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi Wayne, Checked the fuse and found the culprit :). Had me worried for a bit!

Subject: Re: No power from my Wharfdale Active Pro 8.2 speaker
Posted by [Wayne Parham](#) on Wed, 21 Mar 2007 14:17:53 GMT

[View Forum Message](#) <> [Reply to Message](#)

Very good! That's the easiest PS fix there is! Hopefully, the fuse won't blow again.
