

---

Subject: 3/8" Onkyo tweeter phase plug removal  
Posted by [Jeffery L](#) on Sun, 30 Dec 2007 23:06:15 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

What happens when I remove the phase plug from my 3/8" Onkyo tweeter? How does this affect the sound?

---

---

Subject: Re: 3/8" Onkyo tweeter phase plug removal  
Posted by [real\\_one](#) on Mon, 31 Dec 2007 15:10:30 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

The highest frequencies will go away if you remove the phase plug. Its purpose is to prevent cancellation.

---